



Instruction

1. Get out all parts with fittings and check them carefully.
2. Find out “1 base” and “2 connector”,fasten them firmly with “fasteners 1”.
3. Pull out zinc pipe in “3 base upright”,connect “3 base upright” to “1 base”.
4. Screw the flower shape bolt and height adjust pin to “3 base upright”,height adjust pin must be firmly screwed.



5. Connect the “4 crossbar” between zinc pipe,bolts them firmly.
6. Insert the zinc post to “3 base upright”,tighten all screws.
7. Insert “5 extension” to “1 base”,screw down the small blue slower shape bolts.
8. Connect all “5 extension” with “2 connector”
9. Check all bolts,connections,make sure they are all deadly screwed.